

Perform the following steps to update the firmware in the BITE5.

1. Turn off the BITE5.
2. Remove the SD Card from the BITE5.

Connections

Mini USB input and micro SD card slot

Current probe input

Voltage lead inputs

Impedance probe inputs

ON/OFF switch

DC power adapter input




3. Plug SD card into USB adapter supplied with BITE5.

4. Plug USB adapter with SD card into PC



5. Download and copy the file "UPDATE.DAT" to the root of the BITE5 SD card. (ex: D:\UPDATE.DAT)



6. Insert the SD card back into BITE5.

7. Turn on BITE5 power.

8. Follow instructions on BITE5 display.